

### **TIMED WATERING:**

Turn dial clockwise and align the desired number of minutes with the **TIME INDICATOR**. To turn off before time runs out, rotate the dial back to 0 and push up on the release lever to turn off.

### **MANUAL (NON TIMED) WATERING:**


Depress the **RELEASE LEVER** and rotate dial counter clockwise to "Manual On". Water will stay on unless you turn it off. Rotate back to "0" and push up on release lever to turn water off.

### **RIEGO PROGRAMADO:**

Gira el indicador en sentido de las manecillas del reloj y alinea la cantidad deseada de minutos en el **INDICADOR DE TIEMPO**. Para apagarlo antes de que termine el tiempo, rótao a 0 y hala la palanca de liberación.

### **RIEGO MANUAL (SIN TEMPORIZADOR):**

Baja la **PALANCA DE LIBERACIÓN** y rota el indicador en el sentido contrario de las agujas del reloj a la posición "Manual on". Seguirá saliendo agua a menos que lo apagues. Rótao a "0" y hala la palanca de liberación para cerrar el agua.



**SKU 480-616**  
Model 56908

**Release Lever**  
Palanca de liberación

**Time Indicator**  
Indicador de tiempo

